

Stainless Steel Side & Bottom Lab-Frame Kit, 6-Foot

Lattice Frame:

Use the open connectors and lattice rods to assemble the frame. The kit assumes a lattice spacing of 1-foot; however, this may vary depending on your application. Rods may be cut for fit as necessary.

Mounting:

Attach vertical base plates to the horizontal and vertical rod ends. Base plates may be secured with #10 screws. **Mounting Screws Not Included.**

NOTE: Follow your fume hood manufacturers' requirements for attachment.



36" Rods **X 5**
62" Rods **X 2**



X 10



X 9

