

# Aluminum Side & Bottom Lab-Frame Kit, 8-Foot

## Lattice Frame:

Use the open connectors and lattice rods to assemble the frame. The kit assumes a lattice spacing of 1-foot; however, this may vary depending on your application. Rods may be cut for fit as necessary.

## Mounting:

Attach vertical base plates to the horizontal and vertical rod ends. Base plates may be secured with #10 screws. **Mounting Screws Not Included.**

*NOTE: Follow your fume hood manufacturers' requirements for attachment.*

